


## Flash Fog 3000 – User Instructions



**Power Dial:** Interval in minutes until next fog blast when timer is on

**Output Dial:** Duration in seconds of fog blast when timer is on

**Volume Dial:** Fog output/strength in timer and manual mode.

**Manual Switch:** Dot pressed down (manual release) Dot pressed up (timer mode)

**Wireless Remote:** Numbers will work only if on receiver dip switch is switched towards the number

**TIMER LED:** When the Timer green LED is flashing, it means the timer is about to shoot fog soon.

**READY LED:** When green LED is on, the fog machine is charged and ready to go

*Duration and Interval settings are approximate*