

30 programs:

A. Twinkle various colours & strobe
(all modes rotation?)

1. Infection – colour spread (all colours)
2. 0-100 % brightness. colour rotation. All LEDS on at same time
3. Random colour twinkle
4. Quicker random colour twinkle
5. Infection/Colour Twinkle – Quick and sporadic
6. Same?
7. 0-100% random colours -> twinkle
8. White Twinkle****
9. Colour Cycle -> All LEDS same colour at once
10. White Strobe ****
11. Infection & Spasm
12. All colour twinkle
13. Greens/Blues – Cross Dissolves
14. Infection – red/green/blue
15. Infection/Colour Twinkle
16. Strobe Pink
17. Strobe Red
18. Strobe Green
19. Strobe Bright Pink
20. Strobe Blue
21. Strobe Yellow
22. Strobe White
23. Constant Red
24. Constant Green
25. Constant Blue
26. Constant Yellow
27. Constant Pink
28. Constant White
29. 0-100 % brightness. colour rotation. All LEDS on at same time
30. Strobe White

Speed: Hold “UP” until red dot in bottom right.

Speed 1-15

Brightness: Hold “UP” until red dot in bottom right, hold again till in bottom left

- .C Brightness
- .b = Auto brightness
- .A = Auto?
- 3= low
- 2= Med
- 1= High
- 0= Highest

Audio Sensitivity: Hold “UP” until red dot in bottom right, hold again till in bottom left, again till in both corners
Change from 0-9

DMX: Hold “Down” -> Then set channel

REMOTE:

1-2: Channel

3-4: Speed

5 : Sound Sensitivity NA

6: On/Off